

model-lights OHG

Lit figures, bicycles, motor-bikes, carriages, tractors, trailers, vehicles and accessories

Installation description

Place the figure, bicycle or vehicle on your model plate and mark the position where you want to put the cable (invisible behind the figure or under the vehicle). Drill a 3 mm hole for the cable and resistor to pass through the plate. We recommend you to fix the figure, bicycle or vehicle with **Fixogum** on the model plate because it can be released any time.

Illumination:

There is no need to change the LED because it has an unlimited durability. The cable are connected to 12 - 16V AC/DC. All figures, bycles and vehicles (except figures or vehicles with blinking or flashing effects) have a protective diode, which must be connected to the pluspole (yellow). By using DC you have to take care of the electric pole!

Resistor and protective diode should never be removed!

The use of battery is not allowed!

Do not pull the cable!

Fuse of the electrical equipment:

The fuse of the electrical equipment must be covered up to the maximum capacity, so that a short circuit can be avoided in case of a cable burn.

D

Dieses Produkt ist kein Spielzeug!
Nicht geeignet für Kinder unter 14 Jahre!
Verpackung aufbewahren!

GB

This product is not a toy! Not suitable for children under 14 years! Keep the box!

NL

Dit produkt is geen speelgoed! Niet geschikt voor Kinderen onder 14jaar! Verpakking bewaren!

F

Ce produit n'est pas un jouet! Ne convient pas aux enfants de moins de 14 ans! Conserve zemballage!

E

Esto noes un juguete! Nore comenda do paramenores de 14 anos!
Conserva lacaja!

model-lights oHG
Sophienweg 37
46483 Wesel